

WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product.

Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp. Digital Voice-Memo Recorder and LED Light
- Enclosed copy of original sales receipt.

Name			
Mail Address			
City			
State, Zip Code			
Item Purchased	Digital Voice-Memo Recorder and LED Light		
Stores Name			
Date of Purchase			
Signature		Date	

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service
WAGAN Corporation
3589 Yale Way
Fremont, CA 94538

© 2005 WAGAN Corp.



Item no. 2312

Digital Voice-Memo RecorderTM And LED Light



User's Manual

Thank you for purchasing the Digital Voice-Memo Recorder and LED Light by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.

USING THE LED LIGHT

- The handy and built-in LED light makes finding keyholes in the dark easy
- To turn on the red illuminator light, push and hold the LIGHT button. To turn off the light, release the LIGHT button

USING THE VOICE-MEMO RECORDER

The memo recorder has a slide switch with 3 functions – RECORD/PLAY/LOCK. When in the lock position, the recorder will not work. Also there are two buttons for playing and recording.

1. To record, set the switch REC/PLAY/LOCK to REC
2. Hold down REC button and speak in a loud voice about 4 inches from the microphone. The red indicator lights
3. To stop recording, release the button REC. The red indicator turns off
4. Repeat steps 1-3 to record more messages. Once 20 seconds of messages are recorded, the recorder automatically stops recording and the red indicator turns off
5. To play, set the switch to PLAY
6. Press and release the PLAY button to hear all the recorded messages

7. Note: You must play back the old messages before recording a new message. Once you record new messages, the old messages will be erased
8. When you finish playing or recording,,set REC/PLAY/LOCK to LOCK

Caution: Do not let the recorder touch the magnetic strip on credit cards. The recorder's magnetic field might erase the credit magnetic strip.

REPLACING THE BATTERIES

The Digital Voice-Memo Recorder and LED Light comes with one DC 6V 4LR44 battery for the memo recorder and two DC1.5Y LR44 button batteries for the LED light. Replace the appropriate batteries when the recorder stops operating properly, or the light dims.

1. Remove the screws from the battery compartment cover with a Philip screwdriver
2. Take out the old or weak batteries and replace with new batteries according to polarity symbols marked inside
3. Replace the cover, then inset and tighten the screws

WARNING

1. Keep batteries away from children. Swallowing a button-cell battery can be fatal
2. Please pay attention on the polarity marking on the unit while putting the batteries to operate the unit

SPECIFICATIONS

POWER: one DC 6V 4LR44 battery / two DC 1.5 V LR44 batteries

Maximum Recording Time: 20 seconds

Dimensions: 39.5 x 18 x 72.5 mm (W x D x H)